

Pressing the Special Functions 1 button gets the following Screen:



If the voice was enabled, then it would announce “Special Functions 1 Enhanced Parameters”. If this screen appeared as the result of pressing P5 or P6, then it would announce “Enhanced Parameters”

Pressing P6 would get you to the Enhanced Monitor screen and pressing P5 would get you to the GPS Location screen.

Pressing a number from 1 – 9 will jump directly to the appropriate screen. Pressing P7 will exit from the special functions. Pressing P4 will execute the special function shown on the display. All other keys will generate an error beep.



If the voice was enabled, then it would announce “Enhanced Monitor”.

Pressing P6 would get you to the Enhanced Scanning screen and pressing P5 would get you to the Enhanced Parameter screen.

Pressing a number from 1 – 9 will jump directly to the appropriate screen. Pressing P7 will exit from the special functions. Pressing P4 will execute the special function shown on the display. All other keys will generate an error beep.



If the voice was enabled, then it would announce “Enhanced Scanning”.

Pressing P6 would get you to the GPS Roaming screen and pressing P5 would get you to the Enhanced Monitor screen.

Pressing a number from 1 – 9 will jump directly to the appropriate screen. Pressing P7 will exit from the special functions. Pressing P4 will execute the special function shown on the display. All other keys will generate an error beep.



If the voice was enabled, then it would announce "GPS Roaming".

Pressing P6 would get you to the VFO screen and pressing P5 would get you to the Enhanced Scanning screen.

Pressing a number from 1 – 9 will jump directly to the appropriate screen. Pressing P7 will exit from the special functions. Pressing P4 will execute the special function shown on the display. All other keys will generate an error beep.



If the voice was enabled, then it would announce “VFO”.

Pressing P6 would get you to the Serial Communication screen and pressing P5 would get you to the GPS Roaming screen.

Pressing a number from 1 – 9 will jump directly to the appropriate screen. Pressing P7 will exit from the special functions. Pressing P4 will execute the special function shown on the display. All other keys will generate an error beep.



If the voice was enabled, then it would announce “Serial Communication”.

Pressing P6 would get you to the Satellite screen and pressing P5 would get you to the VFO Screen.

Pressing a number from 1 – 9 will jump directly to the appropriate screen. Pressing P7 will exit from the special functions. Pressing P4 will execute the special function shown on the display. All other keys will generate an error beep.



If the voice was enabled, then it would announce “Satellite Communication”.

Pressing P6 would get you to the Spectrum Display screen and pressing P5 would get you to the Serial Communication screen.

Pressing a number from 1 – 9 will jump directly to the appropriate screen. Pressing P7 will exit from the special functions. Pressing P4 will execute the special function shown on the display. All other keys will generate an error beep.



If the voice was enabled, then it would announce "Spectrum Display".

Pressing P6 would get you to the GPS Location screen and pressing P5 would get you to the Satellite screen.

Pressing a number from 1 – 9 will jump directly to the appropriate screen. Pressing P7 will exit from the special functions. Pressing P4 will execute the special function shown on the display. All other keys will generate an error beep.





If the voice was enabled, then it would announce “GPS Location”.

Pressing P6 would get you to the Enhanced Parameter screen and pressing P5 would get you to the Spectrum Display screen.

Pressing a number from 1 – 9 will jump directly to the appropriate screen. Pressing P7 will exit from the special functions. Pressing P4 will execute the special function shown on the display. All other keys will generate an error beep.

When you press the P4 button to start the appropriate feature and that feature is not currently implemented, the screen will show the following:



If the voice is enabled, then the radio will announce “Feature Not Available”.

There will be a two second delay to allow the user to read the display and then the radio will go back to the display that was there before the P4 key was pressed.

Pressing a numeric key will allow you to go directly to the specified screen. The screen numbers are as follows:

- 1 Enhanced Parameters
- 2 Enhanced Monitor
- 3 Enhanced Scanning
- 4 GPS Roaming
- 5 VFO
- 6 Serial Communication
- 7 Satellite
- 8 Spectrum Display
- 9 GPS Location