


CHANGING CHANNELS WITH THE CS-BFD

With most radios, there are about 4000 channels available to select. With the other radios, you first have to select the zone. That can be up to pressing the zone up button 250 times. Then you have to select the channel within the zone. That can be between 1 and 16 button presses for the CS800D and up to 160 button presses for other radios. With the CS-BFD, we make it easy to select your 16 favorite channels.


STEP 1

Touch the screen where the channel name appears. That will get you to the next picture.



STEP 2

Touch the channel you want to go to.



STEP 3

There is no step 3. Soon as you touch the desired channel you get to the next picture and now you can start using that channel.

CONNECT SYSTEMS



Zone-16

Santiago WA6LIF

ch-88


Rx=446.82000 Tx=441.82000

09

STG World

**DMR
LOW**

Volume



P1

P2

P3

P4



P1

P2

P3

P4

